



1
Open the bonnet and clean thoroughly.



2
Place the bonnet extension upright and toward the windscreen.



3
Line up the bonnet and the bonnet extension.



4
Close the bonnet to ensure the bonnet extension is positioned correctly.



5
Once positioned correctly, degrease the area in which the bonnet extension will stick to.



6
Peel off the red tape around 3-4 cm.



7
Stick the bonnet extension to the bonnet carefully.



8
Once all the red tape is peeled off, press firmly to ensure the bonnet extension is secure.