

POWERFLEX®

PART NUMBER

PF3-1662

DESCRIPTION

VAG MAGNETIC JACKING PAD INSERT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Magnetic Jacking Pad Insert

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Locate the insert in the location you would like to place the jacking pad.
 2. Check the OEM insert is properly mounted in the chassis by ensuring the plastic insert is secure in the rubber casing and that the top of the rubber casing is flush to the body of the vehicle as shown in Figure 1.
 3. Align the jacking pad to the centre of the insert and slot the magnetic section of the insert into the hole. The magnet will then attach itself to the insert, as shown in Figure 2.
 4. Remove any jacking pads from the hydraulic jack and align the jack with the jacking pad. Then raise the jack until it reaches the car, ensuring it stays aligned with the jacking pad.
 5. The car can now be raised to the desired height.
- NB: Volkswagen recommend using all four jacking points simultaneously to raise the vehicle.**
6. When the vehicle has been lowered, ensure the jacking pad is removed to prevent it detaching while the vehicle is in motion.

