

POWERFLEX®

PART NUMBER

PFF5-6004G

DESCRIPTION

FRONT UPPER WISHBONE BUSH ADJUSTABLE

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane Bushes
- 1 x PTFE/Silicone Grease
- 4 x Stainless Steel Sleeves
- 4 x Stainless Steel Washers
- 4 x Nylon Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove OEM wishbone from car and remove original bush from the wishbone.
2. Clean the bore of the wishbone, and remove any burrs and sharp edges.
3. Press the Powerflex bushes into the arm in the orientation shown in Figure 1.
4. Put the Stainless washers onto the offset sleeves, so that the recess mates with the inside of the head of the offset sleeve (Figure 1).
5. Apply some of the supplied grease to the bore of the bush, and then press the sleeve/washer assemblies from Step 4 into the bush, with the knurled head of the sleeve facing outwards from the bush. (Figure 2). Ensure the offset bore of both bushes is as far towards the ball joint as possible.
6. Fit the Nylon washer to the inside face of the bush (Figure 2).
7. Refit wishbone to car and hand-tighten mounting bolts.
8. Perform a wheel alignment check on the vehicle, and adjust the camber to the desired specifications (Figure 3). When adjusting the wheel camber, ensure each sleeve on the wishbone is adjusted in the same direction and by the same amount, to avoid changing other wheel geometries. We do not advise adjusting the bushes in opposing directions.
9. Once wheel alignment is complete, tension all hardware to manufacturers recommended torque settings.

